



GROUPE G&G, DIVISION PRETAL
6245, BLVD. GRANDES-PRAIRES
ST-LEONARD (QUEBEC)

☎ : (514) 325-3711
☎ : (514) 325-3900
Web site: www.pretal.com
E-mail: pretal@pretal.com

MONTHLY MAINTENANCE SCHEDULE ACCESS HATCH

Maximize leaf mobility

Clean the frame all around, removes earth, dirt, sand or rock, calcium or salt (during winter) and any other material accumulation.

Make sure the drain is always free and clean to facilitate water flow.

Make sure the Neoprene is properly place.

Clean and lubricate any pivot (hinges, cylinders, retaining arm) and locks mechanism with WD-40 or any other cleaning lubricant.

In any circumstances the retaining arm must be forced.

When the hatch is located in an area extremely dirty. The maintenance must be done every week.

Important notice:

This warranty will become invalid if products are improperly installed and/or modified, changed, damaged, tampered with or used in an application for which it is not designed and/or not properly maintenance and/or if the owner and/or his employees and/or his sub-contractor act with negligence.